



TM CLEAROXID

DISINFECTING CLEANER IN POWDER FORM FOR WATER DISPENSING SYSTEMS AND ICE DISPENSERS
BASED ON THE THONHAUSER  PERSULPHATE TECHNOLOGIES

- ✓ NOTIFIED DISINFECTANT ACC. TO EU-BIOCIDAL LEGISLATION, CORRESPONDS TO EN 1276
- ✓ GERM REDUCTION RATE: 99,99 % WITHIN 5 MINUTES
- ✓ EASY TO RINSE
- ✓ POWDER EASILY SOLUBLE IN WARM WATER



DISINFECTION OF WATER-DISPENSERS

1) PREPARATION	Always unplug the water dispenser and remove the empty bottle before you start.
2) DISSOLVE POWDER	Add content of 1 packet (50g) of TM CLEAROXID into 2.5 liters of warm water (2%). Shake container well!
3) FILL COOLER & PIPE	Pour TM CLEAROXID-disinfectant solution into water reservoir. Open faucet and leave running until cleaning solution flows through.
4) 20 MINUTES SOAKING TIME	Let soak TM CLEAROXID-disinfectant solution for about 20 minutes.
5) RINSE WITH CLEAN WATER	Empty lines. Fill dispenser with at least 2 liters of clean water and drain rinsing water through open tap. Verify rinsing by using pH test strips: the pH of the rinsing water must match the pH of your clean water.

ADVANTAGES OF TM CLEAROXID

- highly effective against all viruses, bacteria, germs, spores, etc.
- kills germs 10 times faster than conventional disinfectants, even in cold temperatures
- small packages guarantee clean handling, powder is easily soluble
- free of chlorine and alcohol – completely environmentally friendly and safe for all acid resistant surfaces
- application solution is non-toxic and non-corrosive

TIP: Use TM CLEAROXID to disinfect the surfaces of plexiglass and plastic spouts!
Add 1 pouch of TM CLEAROXID-powder into a 1 liter spray bottle, fill it up with warm water - shake briefly - done.
This solution is active for 3-4 days, after this time prepare fresh solution.



DELIVERY	Box of 200 packets each 50 grams. One pouch is used for preparation of 2.5 Liters of TM CLEAROXID-solution.
PH VALUE	pH 2.8 (concentration of 2%)
SHELF LIFE	powder is stable for 24 months when stored at -30 up to + 50°C. The TM CLEAROXID solution is active for 3 -4 days.
DISPOSAL	The used TM CLEAROXID solution is drained off with rinsing water into sewage, has no negative effect on sewage treatment plants.
HAZARD IDENTIFICATION	Oxidizing, Corrosive, Irritant, Health hazard. For more information please consult the Material Safety Data Sheet.
Use biocides safely. Always read the label and product information before use!	
24/7 Poisoning Emergency Hotline: + 43 - 1 - 406 43 43	

HEADQUARTERS ÖSTERREICH:
Thonhauser GmbH
Perlhofgasse 2/1
A 2372 Gießhübl
Tel +43 (0)2236 / 320 272